


TOP AND CONSOLE PARTS

27" GAS DRYER

For Models: WGD5700XW1, WGD5700XL1

(White)

(Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: WGD5700XW1, WGD5700XL1

(White) (Silver)


Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10096984	Installation Instructions
	W10097053	Guide, Use & Care
	W10097034	Tech Sheet
2		Assembly, Console
	W10269611	White
	W10293251	Silver
3		Knob Assembly
	W10251392	White
	W10251394	Silver
4	W10269626	User Interface
5	W10323092	Seal, UI
6	W10274524	Tensioner
7	W10123956	Sound Panel
8	W10285494	Cable, User Interface
9	W10096969	Panel, Rear Console
10	693995	Screw, 8-16 x 3/8
11	W10325119	Spacer, Knob
12		Top
	W10260246	White
	W10268729	Silver
13	3390647	Screw, 8-18 x 1/2
14	8312709	Clip, Console
15	W10338363	Cover, Terminal Block
16	W10279552	Plug, Upper Rear Panel
17	3390814	Screw, 8-18 x 1/2
18	8536939	Clip, Spring
19	W10287253	Harness, Wiring
20	W10298336	Screw
21	W10219342	Screw, 8-16 x 1/2
22	W10271580	Bracket, Motor
23	W10214008	Electronic Control
24	W10280079	Seal, Console

CABINET PARTS

For Models: WGD5700XW1, WGD5700XL1

(White)

(Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: WGD5700XW1, WGD5700XL1

(White) (Silver)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	697773	Screw, 6–20 x 7/8	13	3388672	Pulley Assembly	32	W10242878	Bracket, Motor
2	8529757	Bracket, Burner	14	343641	Screw, 10–16 x 1/2	33	8563749	Exhaust Pipe (Long)
3	3406107	Door Switch Assembly	15	8533971	Screw, Ground	34	W10336128	Foam, Cabinet
4	3394331	Plate, Cover	16	3390647	Screw, 8–18 x 1/2	35	W10312811	Foam Seal
5	W10246525	Switch, Broken Belt	17	8563747	Exhaust Pipe & Bracket	36	693152	Bumper
6	344020	Cord, Power Cabinet	18	W10121334	Washer, Thrust	37	3387242	Seal, Front Panel
7	8310656	White	19	W10291934	Clip (2)	38	696144	Strike, Door
	W10292891	Silver	20	690997	Tri–Ring	39	3388674	Idler Bracket
8	3392100	Foot, Dryer	21	W10236068	Bracket, Cabinet	40		Toe Panel (Includes. Illus. 36)
	279810	Foot – Optional (Extended Length Package Of 2) (Not Included)	22	3387565	Spring, Door (2)		697215	White
9	660658	Clamp, Motor (2)	23	3357011	Screw, 10–16 x 1/2		W10292896	Silver
10	3387374	Spring, Idler	24	3388229	Retainer	<hr/> Optional Parts Not Included <hr/>		
11	3389420	Retainer, Idler	25	49026	4" – 90° Elbow	<hr/> Dryer Exhaust Kit (For Side & Bottom Venting) <hr/>		
12	49252	White	26	697227	Upper Front Panel White			
	W10151499	Midnight Grey		W10292893	Silver	41	W10331132	Midnight Grey
			27	3395650	Motor, Assembly 1/3 HP			
			28	8563750	Exhaust Pipe (Short)			
			29	8578220	Pulley, Motor			
			30	3387610	Belt, Drive			
			31	693995	Screw, 8–18 x 3/8			

BULKHEAD PARTS

For Models: WGD5700XW1, WGD5700XL1

(White)

(Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: WGD5700XW1, WGD5700XL1

(White) (Silver)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10359271	Shaft, Drum Roller (R.H.) Thread	15	8066224	Exhaust Pipe	33	3392519	Thermal Fuse
2	3390647	Screw, 8-18 x 1/2	16	W10001120	Nut, 3/8-16 (L.H.)	34	3387223	Electrode, Sensor
3	90767	Screw, 8-18 x 3/8	17	8520836	Bulkhead, Rear	35	3402841	Lens, Drum Light
4	3394986	Spring, Lint Screen Door	18	3387459	Washer, Support	36	3406124	Bulb, Light
5	W10293765	Air Duct Assembly	19	W10359272	Shaft, Drum Roller (L.H.) Thread	37	697772	Wheel, Blower
6	697813	Seal, Outlet Housing	20	690997	Ring, Tri	38	8578825	Bracket, Light
7	697814	Seal, Drum Front	21	W10314171	Roller, Support	39	W10214261	Socket, Assembly
8	3934666	Nut, 3/8 x 16(R.H.)	22	695240	Screw, 8-18 x 1/2	40	697770	Seal, Cover Plate
9	338906	Sensor, Radiant	23	W10153423	Outlet Housing Assembly	41	W10049370	Lint Screen
10	3387230	Screw, 10-16 x 3/16	24	W10305870	Harness, Gas	42	8577274	Thermostat, Internal Bias
11	W10153414	Housing, Outlet	25	8318215	Complete Drum Assembly	43	3391912	Thermostat, High-Limit (255)
12	W10128629	Shield, Blower Housing	26	W10219342	Screw, 8-16 x 3/4	44	8544362	Housing, Blower
13	697693	Baffle, Drum	27	W10166807	Seal, Drum	45	8066168	Lint Duct Assembly
14	W10153413	Door, Lint Screen	28	693995	Screw, 8-16 X 3/8	46	8573824	Funnel, Burner
			29	697557	Bulkhead, Front	47	W10298258	Harness, Sensor
			30	8572105	Clip, Exhaust	48	8573713	Thermal, Cutoff
			31	489463	Screw	49	3401707	Jumper, TCO Hi-Limit
			32	W10153412	Grille, Outlet	50	W10345456	Clip, Spring


W10293911 BURNER ASSEMBLY

For Models: WGD5700XW1, WGD5700XL1

(White)

(Silver)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED,
AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10293911 BURNER ASSEMBLY

For Models: WGD5700XW1, WGD5700XL1

(White) (Silver)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED,
AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	W10293911	Burner Assembly 60 Hz. (Type 1 & 2)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 5/8)
6	343641	Screw, 10-16 x 1/2
7	3389871	Base, Burner
8	3387057	Screw, 8-18 x 3/8 (3)
9	15418	Orifice, Burner Type 1
10	W10175144	Valve, Gas 60 Hz. (Complete) (Includes Pipe & Illus. No. 7)
11	W10295524	Sleeve-Magnetic
12	3389889	Bracket, Support
13	W10273784	Coil, 60 Hz.
14	3978776	Clamp, Pipe
15	326049536	Screw, Coil
16	3390647	Screw, 8-18 x 1/2
17	W10295523	Plug, Pipe

Following Parts Not Illustrated


W10293913 Conversion Kit
(Type 1 and 2)
to Type (4) L.P.G.

DOOR PARTS

For Models: WGD5700XW1, WGD5700XL1

(White)

(Silver)



Illus. No.	Part No.	DESCRIPTION
1		Outer Door Assembly
	W10284124	White
	W10284142	Silver
3	3357011	Screw, 10-16 x 1/2
4	W10284123	Seal, Door

Illus. No.	Part No.	DESCRIPTION
5	3393258	Screw, 10-16 X 1/2
6	690081	Assembly, Door Catch
7	W10284133	Door, Inner
8	W10284121	Door, Glass
9	W10284122	Seal, Window
10	W10284120	Retainer, Lower Glass

Illus. No.	Part No.	DESCRIPTION
11	W10284119	Retainer, Upper, Glass
12	W10284179	Door Inner Assembly
13	W10284141	Hinge, Door (R.H.)
14	W10284140	Hinge, Door (L.H.)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: WGD5700XW1, WGD5700XL1

(White)

(Silver)

Illus.	Part	
No.	No.	DESCRIPTION

ACCESSORY PARTS

	80047	Kit, Dryer Repair
	8522199	Kit, Dryer Vent Testing
	346764	Kit, Hold-Down (Gas Dryer Mobile Home Installation)
	8212450A	Dryer Rack

PAINT, TOUCH-UP (1/2oz.)

	72017	White
	W10268217	Cosmetallic

PAINT, PRESSURIZED SPRAY (12 oz.)

	350930	White
	350938	Primer, Gray

PAINT, BULK (1 qt.)

	799344	White (Uncut)
--	--------	---------------