Sears

REPAIR PARTS LIST

Model No.(s)

110.21182012
(White)

Kenmore

AUTOMATIC WASHER

The model number of your automatic washer is found on the serial plate located at the rear center of the lid well.

All repair parts listed are available for immediate purchase or special order when you visit your nearest Sears Service Center, or the Service Department at most Sears stores. To order parts by phone, call the toll free parts number listed to the left.

When requesting service or ordering parts, always provide the following information:

- Product Type
- Model Number
- Part Number
- Part Description

To Call
Toll Free
For Parts:

1−800−366−PART
(1−800−366−7278)

For Service:

1−800−4−MY−HOME
(1−800−469−4663)

Sears Brands Managment Corporation, Hoffman Estates, IL 60179

© 2011 Sears Brands Management Corporation

8−11 Litho in U.S.A. (JLP)(bay)

Part No. W10444981 Rev. A

TOP AND CABINET PARTS

For Model: 110.21182012
(White)



TOP AND CABINET PARTS

For Model: 110.21182012
(White)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10280537	Installation Instructions
	W10280511	Use & Care Guide
	W10280489	Tech Sheet
	W10062939	Energy Guide
2	W10251299	Top
3	W10251302	Lid (Includes Item 4)
4	9724509	Bumper, Lid
5	9740848	Screw, 8−18 x 1/2
6		Hinge, Lid
	91770	Left
	54583	Right
7	W10119872	Screw, Lid Hinge
8	W10240513	Strike, Lid Lock
9	W10273971	Screw, 6−19 x 1/2
10	W10192089	Dispenser, Bleach
11	W10392041	Bezel, Lid Lock
12	21258	Bearing, Lid Hinge
13	90016	Clip, Lid Lock Harness
14	W10238287	Latch, Lid Lock Assembly
15	8281163	Screw, 8−16 x 1/2
16	W10250884	Panel, Rear
17	W10251994	Cabinet (Includes Items 22 & 30)
18	W10215098	Brace, Cabinet Top − Front
19	W10215099	Brace, Cabinet Top − Rear
20	1157158	Screw, 8−18 x 3/8
21	W10248088	Lock, Top
22	W10335586	Foot Assembly, Leveling
23	W10215102	Hinge, Top
24	W10142728	Screw, 8−32 x 3/8
25	W10215139	Cover, Harness
26	3400076	Screw, 10−23 x 5/8
27	W10221546	Hose, Outer Drain Assembly (Includes Items 28 & 29)
28	W10280024	U−Bend, Drain Hose
29	356138	Clamp, Hose
30	W10414221	Sound Damper
31	W10339879	Cable Tie
32	W10332870	Pad, Lid Hinge
33	3359452	Nut, Locking

CONTROLS AND WATER INLET PARTS

For Model: 110.21182012
(White)



CONTROLS AND WATER INLET PARTS

For Model: 110.21182012
(White)

Illus. No.	Part No.	DESCRIPTION
1	W10338637	Panel, Console
2	8536939	Clip, Knob
3	W10251358	Cap, End (L.H.) (Includes Item 5)
4	W10251355	Cap, End (R.H.) (Includes Item 5)
5	8312709	Clip, Console
6	W10438104	Control Unit Assembly, Machine & Motor
7	W10420985	Panel, Console Rear Cover
8	1157158	Screw, 8−18 x 3/8
9	W10268912	Switch, Water Level
10	90767	Screw, 8−18 x 3/8
11	W10276649	Cord, Power
12	3400076	Screw, Power Cord Ground
13	W10327522	Knob, Timer
14	W10327523	Knob, Control
15	W10285512	Switch, Rotary Encoder
16	W10291174	Harness, Upper
17	W10357184	Inlet Assembly, Water
18	W10356257	Valve, Water Mixing
19	W10334611	Vacuum Break
20	W10238347	Hose, Vacuum Break
21	W10117298	Clamp, Hose
22	W10344775	Harness, Valve
23	8281163	Screw, 8−16 x 1/2
24	W10251309	Pushbutton, Start
25	W10348582	Clamp

BASKET AND TUB PARTS

For Model: 110.21182012
(White)



BASKET AND TUB PARTS

For Model: 110.21182012
(White)

Illus. No.	Part No.	DESCRIPTION
1	8533251	Dispenser, Fabric Softener
2	8533943	Screw, 10−16 X 3/4
3	W10298887	Cable Tie
4	W10003790	Screw & Washer Assembly
5	3949550	Washer
6	3361598	Agitator, Complete Assembly
7	3363662	Cam, Driven
8	3366877	Dog, Agitator Clutch
9	3363661	Bearing, Cam
10	3360824	Auger Agitator
11	3350389	Spacer, Thrust
12	389386	Agitator
13	W10215108	Ring, Tub
14	21366	Nut, Spanner
15	W10358261	Basket Assembly
16	389140	Block, Basket Drive
17	W10339098	Shield, Splash
18	W10238320	Tub (Includes Item 19)
19	W10006371	Seal, Tub
20	W10215093	Filter, Drain Pump
21	8533928	Screw, 8−18 x 3/4
22	W10257088	Damper Assembly, Tub Suspension (Set Of 4−Includes Items 23 & 24)
23	W10215136	Ball, Suspension (Set Of 4 − Includes Item 24)
24	W10256551	Bushing, Suspension (Set Of 4 − Includes Item 23)
25	W10297444	Harness, Lower (Includes Items 3 & 26)
26	W10297436	Hose, Pressure Switch
27	W10005430	Clamp, Pressure Hose Retainer
28	W10348658	Spring, Tub Centering
29	W10273613	Retainer, Push In

GEARCASE, MOTOR AND PUMP PARTS

For Model: 110.21182012
(White)



Illus. No.	Part No.	DESCRIPTION
1	W10276397	Pump Assembly, Drain
2	W10004910	Screw, 12−16 x 1.25
3	W10215091	Hose, Inner Drain Assembly
4	8317496	Clamp, Hose
5	W10006378	Gearcase Assembly
6	W10249633	Screw, 7.2−1.6 x 30
7	W10006415	Motor, Drive
8	W10094780	Screw, M8−1.25 x 20
9	W10006382	Spring, Splutch (Includes Items 10, 11, 12 & 13)
10	W10006352	Slider, Splutch (Includes Items 9, 11, 12 & 13)
11	W10006353	Cam Ring, Splutch (Includes Items 9, 10, 12 & 13)
12	W10006354	Cam, Splutch (Includes Items 9, 10, 11 & 13)
13	W10006356	Pulley
14	W10163336	Nut, Pulley
15	W10006384	Belt, Drive
16	W10006355	Actuator, Shift
17	9741052	Screw, 6−32 x 1.00
18	W10278556	Capacitor, Motor Run
19	357640	Screw, 10−16 x 5/8
20	W10006383	Shield, Pulley Cover

OPTIONAL PARTS (NOT INCLUDED)

For Model: 110.21182012
(White)

Illus. No.	Part No.	DESCRIPTION
PAINT, TOUCH−UP (1/2oz.)		
	72017	White
PAINT, PRESSURIZED SPRAY (12 oz.)		
	350938	Primer, Gray
	350930	White
PAINT, BULK (1 qt.)		
	799344	White (Uncut)

Illus. No.	Part No.	DESCRIPTION
WATER SYSTEM PARTS		
	285835	Connector Kit, 4" Hose With Clamp
	285863	Hose Extension − 4 Foot With Clamp
	285834	Siphon Break Kit
	367031	Drain Protector
	3363920	Adapter, Standpipe 2" Diameter to 1" Diameter
	DRNEXT4	Drain Hose Extension Kit
SEALER		
	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
COUPLING		
	384496	Coupling, Hose

Illus. No.	Part No.	DESCRIPTION
ACCESSORY PARTS		
	W10135699	Affresh Odor Remover
	8212546RP	Inlet Hoses, 4 Ft. (Two Black Hoses W/Straight Ends & 4 Rubber Washers)
	8212641RP	Inlet Hoses, 5 Ft. (Two Black Hoses W/Straight Ends & 4 Rubber Washers)
	8212545RP	Inlet Hoses, 5 Ft. (One Red Hose & One Blue Hose W/Straight Ends & 4 Rubber Washers)
	8212487RP	Inlet Hoses, 5 Ft. (Two Braided Hoses W/Straight Ends & 4 Rubber Washers)
	8212637RP	Inlet Hoses, 6 Ft. (Two Black Hoses W/ One Straight End & One 90 Degree End & 4 Rubber Washers)
	8212638RP	Inlet Hoses, 6 Ft. (Two Braided Hoses W/ One Straight End & One 90 Degree End & 4 Rubber Washers)
	8212656RP	Inlet Hoses, 10 Ft (Two Black Hoses W/ Straight Ends & 4 Rubber Washers)
	285448A	Hose Washers (Package of 4)
	285452A	Hose Screen (Package of 2)
	8212526	Washer Drip Tray
	W10355010	All Purpose Appliance Cleaner