TOP AND CABINET PARTS

AUTOMATIC WASHER

For Model: 4GNTW4400YQ0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CABINET PARTS

For Model: 4GNTW4400YQ0
(White)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10454261	Installation Instructions
	W10462976	Use & Care Guide
	W10280489	Tech Sheet
2	W10251299	Top
3	W10251302	Lid (Includes Item 4)
4	9724509	Bumper, Lid
5	9740848	Screw, 8−18 x 1/2
6	91770	Hinge, Lid
7	W10119872	Screw, Lid Hinge
8	W10240513	Strike, Lid Lock
9	W10273971	Screw, 6−19 x 1/2
10	W10192089	Dispenser, Bleach
11	W10392041	Bezel, Lid Lock
12	21258	Bearing, Lid Hinge
13	90016	Clip, Lid Lock Harness
14	W10294102	Lock, Lid
15	8281163	Screw, 8−16 x 1/2
16	W10250884	Panel, Rear
17	W10251994	Cabinet (Includes Item 22)
18	W10215098	Brace, Cabinet Top Front
19	W10215099	Brace, Cabinet Top Rear
20	1157158	Screw, 8−18 x 3/8
21	W10248088	Lock, Top
22	W10335586	Foot Assembly, Leveling
23	W10215102	Hinge, Top
24	W10142728	Screw, 8−32 x 3/8
25	W10215139	Cover, Harness
26	3400076	Screw, 10−23 x 5/8
27	W10221546	Hose, Outer Drain Assembly (Includes Items 28 & 29)
28	W10280024	U−Bend, Drain Hose
29	356138	Clamp, Hose
30	W10339879	Cable Tie
31	3359452	Nut, Locking

CONTROLS AND WATER INLET PARTS

For Model: 4GNTW4400YQ0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROLS AND WATER INLET PARTS

For Model: 4GNTW4400YQ0
(White)

Illus. No.	Part No.	DESCRIPTION
1	W10449048	Panel, Console
2	8536939	Clip, Knob
3	W10251358	Cap, End (L.H.) (Includes Item 5)
4	W10251355	Cap, End (R.H.) (Includes Item 5)
5	8312709	Clip, Console
6	W10455302	Control Unit Assembly, Machine & Motor
7	W10420985	Panel, Console Rear Cover
8	1157158	Screw, 8−18 x 3/8
9	W10268911	Switch, Water Level
10	90767	Screw, 8−18 x 3/8
11	W10422755	Cord, Power
12	3400076	Screw, Power Cord Ground
13	W10327522	Knob, Timer
14	W10327523	Knob, Control
15	W10285512	Switch, Rotary Encoder
16	W10291178	Harness, Upper
17	W10337066	Inlet Assembly, Water
18	W10336726	Valve, Water Mixing
19	W10441423	Vacuum Break
20	W10238347	Hose, Vacuum Break
21	W10117298	Clamp, Hose
22	W10344775	Harness, Valve
23	8281163	Screw, 8−16 x 1/2
24	3400818	Screw, 8−18 x .20
25	W10348582	Clamp
26	W10251309	Pushbutton, Start
27	W10242307	Washer, Water Inlet
28	W10194210	Hose, Inlet (Cold)
	W10196191	Hose, Inlet (Hot)
29	353362	Washer, Filter
30	W10269488	Connector, Y Hose
31	3357450	Washer, Hose

BASKET AND TUB PARTS

For Model: 4GNTW4400YQ0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BASKET AND TUB PARTS

For Model: 4GNTW4400YQ0
(White)

Illus. No.	Part No.	DESCRIPTION
1	3355758	Cap, Agitator
2	W10003790	Screw & Washer Assembly
3	3949550	Washer
4	3951632	Agitator
5	W10215108	Ring, Tub
6	21366	Nut, Spanner
7	W10358261	Basket Assembly
8	389140	Block, Basket Drive
9	W10339098	Shield, Splash
10	W10238320	Tub
11	W10006371	Seal, Tub
12	W10215093	Filter, Drain Pump
13	8533928	Screw, 8−18 x 3/4
14	W10257088	Damper Assembly Tub Suspension (Set of 4 Includes Items 15 & 16)
15	W10405423	Ball, Suspension (Set of 4)
16	W10256551	Bushing, Suspension (Set of 4)
17	W10422641	Harness, Lower (Includes Items 18 & 21)
18	353244	Hose, Pressure Switch
19	W10005430	Clamp, Pressure Hose Retainer
20	8533943	Screw, 10−16 x 3/4
21	W10298887	Cable Tie
22	W10429200	Retainer, Push In
23	3354733	Cap, Barrier
24	W10072840	Seal, Inner Cap
25	3951650	Cam, Driven
26	3366877	Dog, Clutch
27	3952374	Cam, Bearing
28	3363003	Clothes Mover
29	3951608	Spacer, Thrust
30	3951744	Agitator

GEARCASE, MOTOR AND PUMP PARTS

For Model: 4GNTW4400YQ0
(White)



Illus. No.	Part No.	DESCRIPTION
1	W10297344	Pump Assembly, Drain
2	W10004910	Screw, 12−16 x 1.25
3	W10444123	Hose, Inner Drain Assembly (Includes Item 4)
4	8317496	Clamp, Hose
5	W10006378	Gearcase Assembly
6	W10249633	Screw, 7.2−1.6 x 30
7	W10249626	Motor, Drive
8	W10094780	Screw, M8−1.25 x 20
9	W10006382	Spring, Splutch (Includes Items 10, 11, 12 & 13)
10	W10006352	Slider, Splutch (Includes Items 9, 11, 12 & 13)
11	W10006353	Cam Ring, Splutch (Includes Items 9, 10, 12 & 13)
12	W10006354	Cam, Splutch (Includes Items 9, 10, 11 & 13)
13	W10006356	Pulley
14	W10163336	Nut, Pulley
15	W10006384	Belt, Drive
16	W10249623	Actuator, Shift
17	9741052	Screw, 6−32 x 1.00
18	W10349182	Capacitor, Motor Run
19	357640	Screw, 10−16 x 5/8
20	W10006383	Shield, Pulley Cover
21	W10238318	Counterweight
22	W10238319	Screw, 8−18 x 1.00

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Model: 4GNTW4400YQ0
(White)

Illus. No.	Part No.	DESCRIPTION

PAINT, TOUCH−UP (1/2oz.)

72017	White

PAINT, PRESSURIZED SPRAY (12 oz.)

350938	Primer, Gray
350930	White

PAINT, BULK (1 qt.)

799344	White (Uncut)

Illus. No.	Part No.	DESCRIPTION

WATER SYSTEM PARTS

285834	Siphon Break Kit
367031	Drain Protector
3363920	Adapter, Standpipe 2" Diameter to 1" Diameter

SEALER

285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)

COUPLING

384496	Coupling, Hose
DRNEXT4	Drain Hose Extension Kit

Illus. No.	Part No.	DESCRIPTION

ACCESSORY PARTS

W10135699	Affresh Odor Remover
8212546RP	Inlet Hoses, 4 Ft. (Two Black Hoses W/Straight Ends & 4 Rubber Washers)
8212641RP	Inlet Hoses, 5 Ft. (Two Black Hoses W/Straight Ends & 4 Rubber Washers)
8212545RP	Inlet Hoses, 5 Ft. (One Red Hose & One Blue Hose W/Straight Ends & 4 Rubber Washers)
8212487RP	Inlet Hoses, 5 Ft. (Two Braided Hoses W/Straight Ends & 4 Rubber Washers)
8212637RP	Inlet Hoses, 6 Ft. (Two Black Hoses W/ One Straight End & One 90 Degree End & 4 Rubber Washers)
8212638RP	Inlet Hoses, 6 Ft. (Two Braided Hoses W/ One Straight End & One 90 Degree End & 4 Rubber Washers)
8212656RP	Inlet Hoses, 10 Ft (Two Black Hoses W/ Straight Ends & 4 Rubber Washers)
285448A	Hose Washers (Package of 4)
285452A	Hose Screen (Package of 2)
W10355010	All Purpose Appliance Cleaner
8212526	Washer Drip Tray