

COOKTOP PARTS

For Models: YKES907SB01, YKES907SW01, YKES907SS01

(Black)

(White)

(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	2	9758799	Bracket, Indicator Light	12		Element, Surface
	W10118260	Installation Instructions					8203525	LR,1800/1000W
		Use & Care Guide	3	9761422	Frame, Cooktop Side		8523696	RF/1800W
	W10118258	English	4		Cooktop		4453909	LF/RR,2500/1200W
	W10118259	French		W10110271	Black/Stainless	13	9761423	Frame, Cooktop Front
		Tech Sheet		W10110269	White	14	3196537	Screw
	W10112097	English	5	8523739	Indicator, Lamp	15	341196	Thermostat
	W10112098	French			Hot Surface	16	3196160	Screw
	9763467	Easy Set Guide	7	W10076030	Gasket (2)	19	9759094	Spring, Locator
	9757680	Anti-Tip Instructions	9	9759944	Thermostat	20	9761768	Frame, Cooktop Rear
		Safe Cooking Tips	10	9756821	Support, Wiring	21	9763517	Rail, Element (2)
	3191638	English	11	9757825	Rail, Element Center (1)	22	246119	Screw
	9759133	French				23	9761724	Cover, Cooktop Rear

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


OVEN PARTS

For Models: YKES907SB01, YKES907SW01, YKES907SS01

(Black)

(White)

(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: YKESS907SB01, YKESS907SW01, YKESS907SS01

(Black)

(White)


(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side Right	17	4452152	Bracket, Mounting	38	4449743	Screw
	W10109540	Black	18	9757685	Guide, Side Panel	41	W10111628	Transformer, Control
	W10109570	White	19	4451478	Support, Insulation	42	4449868	Block, Terminal
	W10140548	Stainless	20		Body, Side	43	3400080	Screw
		Left		9760723PB	Black/Stainless	44	9759987	Box, Terminal
	W10109490	Black		9760723PW	White	45	9759876	Cover, Terminal Box
	W10109520	White	21	9757461	Bracket, Side Panel	48	9761801	Appliance, Manager
	W10140547	Stainless	22	9760888	Latch, Motorized	49	W10083460	Slide, GOC
2	3400832	Screw	23	9759242	Thermostat	50	9756454	Bracket, Appliance Manager
3		Hinge Receiver	24	9757811	Brace, Side Panel	51	9759884	Insulation
	4455606	Right	25	4455641	Side, Chassis	52	9759722	Insulation, Body Side
	4455605	Left	26	9759761	Back, Chassis	53	9760481	Washer
4	W10105790	Bumper, Door (2)	27		Liner, Oven (Not Serviceable)	54	9758583	Cover, Back
5	3196537	Screw	28	9759890	Clip, Side Panel	56	9759945	Standoff, Rear
6	3196160	Screw	29	W10131825	Sensor	FOLLOWING PARTS NOT ILLUSTRATED		
7	8303099	Top Chassis	30	3196176	Screw	INSULATION		
8	4449809	Screw	31	9759713	Base, Chassis	9756817		Insulation, Wrap
9	4452158	Tube, Vent	32	4448933	Retainer, Gasket	9756470		Insulation, Back
10	W10067870	Lens, Light (2)	33	4448444	Grommet, Mounting Rail			
11	W10009930	Oven Light, Assembly (2)	34		Vent, Bottom Upper			
12	4452166	Bulb, Light (2)	35		Black			
13	4449154	Screw	36	W10116899	White			
14	W10130368	Frame, Front		W10116897	Stainless			
15	W10074200	Gasket, Door		W10160347	Vent, Bottom Lower			
16	9757829	Bracket, Transformer	37	W10104890	Black			
				W10104910	White			
				W10140546	Stainless			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: YKES907SB01, YKES907SW01, YKES907SS01
(Black) (White) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: YKESS907SB01, YKESS907SW01, YKESS907SS01

(Black)


(White)

(Stainless)

Illus. No.	Part No.	DESCRIPTION
1	9759413	Panel, Door
2	9757706	Glass, Inner
3	4451722	Insulation, Door
4	4457132	Retainer, Glass
5		Hinge, Oven Door
	9760579	Right
	9760580	Left
6	9759225	Glass, Inner
7	4457114	Shield, Heat Bottom
8	9759229	Bracket, Glass Side
9	4457103	Shield, Heat Top
10	9759225	Glass, Inner Door
11	9759230	Bracket, Central
12		Bracket, Handle
	9763497	Right
	9763496	Left
13		Badge
	8304603BL	Black
	8304603WH	White
	8304603SS	Stainless
14		Assembly, Door Kit
	W10131888	Black
	W10131889	White
	W10155557	Stainless
15		Handle, Door
	8303774BL	Black
	8303774WH	White
	8303774SS	Stainless
16	3196184	Screw
19	4448520	Bumper, Door

DRAWER PARTS

For Models: YKESS907SB01, YKESS907SW01, YKESS907SS01
(Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Support, Drawer Rail
	9757687	Right
	9757686	Left
2	9763501BL	Support, Front & Rear
3		Brace, Drawer
	4453720	Right
	4453721	Left
5		Side, Base
	9759953	Right
	9759954	Left
6	W10058460	Foot


Illus. No.	Part No.	DESCRIPTION
7	8274149	Thermistor
8	3196037	Foot Assembly
10	W10144430	Wrap, Warming Drawer
11		Drawer Slide
	W10019810	Right
	W10019800	Left
12	W10140544	Panel, Drawer
13		Front, Drawer
	9761747BL	Black
	9761747WH	White
	W10140545	Stainless

Illus. No.	Part No.	DESCRIPTION
14		Handle, Drawer
	9761573BL	Black
	9761573WH	White
	9761573SS	Stainless
15	3196537	Screw
16	W10153100	Cover, Terminal
17	9758676	Support, Element
18	9760775	Element, Warming Drawer
19	9763518	Enclosure, Warming Drawer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: YKES907SB01, YKES907SW01, YKES907SS01
 (Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10117025	Control Panel Black
	W10117027	White
	W10156271	Stainless
2	W10110246	Gasket, Console
3	9761799	Control, Electric
4	W10105370	Shield, Console Vent
5	W10117524	Bracket, Console
6	3196160	Screw


Illus. No.	Part No.	DESCRIPTION
7	9761745	Bracket, Thermostat (2)
8	W10116195	Gasket, Vent Shield
9	3196537	Screw
10	9780271	Screw
11	9761566	Membrane, Switch
12	3196068	Lens, Indicator
13	9763762	Duel, Switch LR,LF,RR
14	9763761	Single, Switch RF

Illus. No.	Part No.	DESCRIPTION
15		Knob, Smart Duel LR,LR,RR
	W10130391	Black
	W10130392	White
	W10156260	Stainless
16		Knob, Smart Single RF
	W10130387	Black
	W10130388	White
	W10156261	Stainless

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: YKES907SB01, YKES907SW01, YKES907SS01
 (Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
2	4449154	Screw
6	4448717	Rack, Oven
7	9760768	Element, Bake
8	9755542	Probe, Meat


Illus. No.	Part No.	DESCRIPTION
9	9760769	Element, Convection
10	9756690	Cover, Fan
11	4455037	Tray, Hidden Bake
12	4450039	Cover, Bake Tray
13	4451583	Motor, Convection

Illus. No.	Part No.	DESCRIPTION
14	4452227	Nut
15	4452226	Blade, Fan
16	9755543	Jack, Meat Probe
17	9755547	Lock Washer
18	9755546	Hex Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: YKES907SB01, YKES907SW01, YKES907SS01
 (Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent Top
3	9759320	Blower
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
7	4449809	Screw (2)
10	4449040	Screw
11	4455352	Bracket, Blower

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: YKESS907SB01, YKESS907SW01, YKESS907SS01

(Black)

(White)

(Stainless)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
<p>OPTIONAL PARTS NOT INCLUDED</p> <p><u>PAINT, TOUCH-UP (1/2oz.)</u></p> <p style="padding-left: 20px;">72017 White 261869 Cord Brown 72032 Black</p> <p><u>PAINT, SPRAY</u></p> <p style="padding-left: 20px;">350930 White 261900 Citrine White 830864 Black</p> <p><u>ADHESIVE</u></p> <p style="padding-left: 20px;">591014 Adhesive Loctite (1/3 oz.) 482338 Sealer, Silastic (3 oz.)</p>	<p><u>SPLICING WIRES--25FT.</u></p> <p><u>LENGTH</u></p> <p style="padding-left: 20px;">242828 Wire (12 Ga. 150 c Black) 242820 Wire (14 Ga. 150 c Black) 242821 Wire (14 Ga. 150 c Blue) 242822 Wire (14 Ga. 150 c Brown) 242830 Wire (14 Ga. 200 c Brown) 242823 Wire (14 Ga. 150 c Green) 242824 Wire (14 Ga. 150 c Orange) 242825 Wire (14 Ga. 150 c Red) 242831 Wire (14 Ga. 200 c Red) 242827 Wire (14 Ga. 150 c Yellow)</p>	<p><u>WIRING HARNESS PARTS</u></p> <p style="padding-left: 20px;">W10118728 Harness, Main W10115167 Harness, Cooktop Electric Switch W10118725 Harness, Switch 9762921 Harness, Communication 4452222 Spacer, Harness 9763481 Harness, Ground Strap 9761059 Power Cord 9759922 Conduit, Slide-In 313660 Clip, Ground Wire 4448664 Clamp 9759877 Retainer, Strain Relief 9757778 Bushing, Snap, Split 1" W10076020 Gasket 4449809 Screw 112432 Nut 4450800 Screw, Ground 3400015 Screw, Ground</p> <p><u>Miscellaneous</u></p> <p style="padding-left: 20px;">9782676 Anti-Tip Assembly Filler, Counter Top W10113902A Black W10113903A White W10113901A Stainless</p>

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST