

COOKTOP PARTS

For Models: KESS907SBL02, KESS907SWW02, KESS907SBB02, KESS907SSS02


(Black) (Designer White) (Pure Biscuit) (Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	4		Cooktop	13	9761423	Frame, Cooktop
	W10118260	Installation		W10110271	Black/Stainless			Front
		Instructiions		W10110269	White	14	3196537	Screw
	W10162196	Use & Care Guide		W10110270	Biscuit	15	341196	Thermostat
	W10112097	Tech Sheet	5	9761724	Cover, Cooktop	16	3196160	Screw
	9763467	Easy Set Guide			Rear	17	8523739	Indicator Light,
	9757680	Anti-Tip	6	9763517	Rail, Element			Hot Surface
		Instructions	7	W10076030	Gasket	18	9758799	Bracket, Indicator
		Safe Cooking Tips	9	9759944	Thermostat			Light
	9762761	English	10	9756821	Support, Wiring	19	9759094	Spring, Locator
	W10065852	French	11	9757825	Rail, Element	20	9761768	Frame, Cooktop
					Center			Rear
2	246119	Screw	12		Element, Surface			
3	9761422	Frame, Cooktop		4456507	LR/1000W			
		Side		4453909	LF,RR/1200W			
				8523696	RF/1800W			

OVEN PARTS

For Models: KESS907SBL02, KESS907SWW02, KESS907SBB02, KESS907SSS02

(Black) (Designer White) (Pure Biscuit) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: KESS907SBL02, KESS907SWW02, KESS907SBB02, KESS907SSS02

(Black) (Designer White) (Pure Biscuit) (Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side Right	17	4452152	Bracket, Mounting	38	4449743	Screw
	W10109540	Black	18	9757685	Guide, Side Panel	39	9758583	Cover, Back
	W10109570	White	19	4451478	Support, Insulation	40	9760481	Washer
	W10109550	Biscuit	20		Body, Side	41	W10111628	Transformer, Control
	W10140548	Stainless		9760723PB	Black/Stainless	43	3400080	Screw
		Left		9760723PW	White	44	W10165135	Box, Terminal
	W10109490	Black	21	9757461	Bracket, Side Panel	45	9757405	Cover, Terminal Box
	W10109520	White	22	9760888	Latch, Motorized	46	9759721	Insulator, Terminal Box
	W10109500	Biscuit	23	9759242	Thermostat	47	9761958	Block, Terminal
	W10140547	Stainless	24	9757811	Brace, Side Panel	48	W10181438	Appliance, Manager
2	3400832	Screw	25	4455641	Side, Chassis	49	W10083460	Slide, GOC
3		Hinge Receiver	26	9759761	Back, Chassis	50	9756454	Bracket, Appliance Manager
	4455606	Right	27		Liner, Oven (Not Serviceable)	51	9759884	Insulation
	4455605	Left	28	9759890	Clip, Side Panel	52	9759722	Insulation, Body Side
4	W10105790	Bumper, Door	29	W10131825	Sensor	FOLLOWING PARTS NOT ILLUSTRATED		
5	3196537	Screw	30	9759945	Standoff, Rear	INSULATION		
6	3196160	Screw	31	3196176	Screw	9756817		Insulation, Wrap
7	8303099	Top Chassis	32	9759885	Pad, Insulation	9756470		Insulation, Back
8	4449809	Screw	33	9759713	Base, Chassis			
9	4452158	Tube, Vent	34	4448933	Retainer, Gasket			
10	W10067870	Lens, Light	35	4448444	Grommet, Mounting Rail			
11	W10009930	Oven Light, Assembly	36		Vent, Bottom Upper			
12	4452166	Bulb, Light		W10116899	Black			
13	4449154	Screw		W10116897	White			
14	W10130368	Frame, Front		W10116898	Biscuit			
15	W10074200	Gasket, Door		W10160347	Stainless			
16	9757829	Bracket, Transformer	37		Vent, Bottom Lower			
				W10153486	Black			
				W10153488	White			
				W10153487	Biscuit			
				W10154789	Stainless			

DOOR PARTS

For Models: KESS907SBL02, KESS907SWW02, KESS907SBB02, KESS907SSS02
(Black) (Designer White) (Pure Biscuit) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS


For Models: KESS907SBL02, KESS907SWW02, KESS907SBB02, KESS907SSS02
 (Black) (Designer White) (Pure Biscuit) (Stainless)

Illus. No.	Part No.	DESCRIPTION
1	9759413	Panel, Door
2	9757706	Glass, Inner
3	4451722	Insulation, Door
4	4457132	Retainer, Glass
5		Hinge, Oven Door
	9760579	Right
	9760580	Left
6	9759225	Glass, Inner
7	4457114	Shield, Heat Bottom
8	9759229	Bracket, Glass Side
9	4457103	Shield, Heat Top
10	9759225	Glass, Inner Door
11	9759230	Bracket, Central
12		Bracket, Handle
	9763497	Right
	9763496	Left
13		Badge
	8304603BL	Black
	8304603WH	White
	8304603BT	Biscuit
	8304603SS	Stainless
14		Assembly, Door Kit
	W10131888	Black
	W10131889	White
	W10131890	Biscuit
	W10155557	Stainless
15		Handle, Door
	8303774BL	Black
	8303774WH	White
	8303774BT	Biscuit
	8303774SS	Stainless
16	3196184	Screw
17	4448520	Bumper, Door

DRAWER PARTS

For Models: KESS907SBL02, KESS907SWW02, KESS907SBB02, KESS907SSS02

(Black) (Designer White) (Pure Biscuit) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Support, Drawer Rail
	9757687	Right
	9757686	Left
2	9763501BL	Support, Front & Rear
3		Brace, Drawer
	4453720	Right
	4453721	Left
4	W10162096	Screw
5		Side, Base
	9759953	Right
	9759954	Left


Illus. No.	Part No.	DESCRIPTION
6	W10058460	Foot
7	8274149	Thermistor
8	3196037	Foot Assembly
10	W10144430	Drawer
11		Drawer Slide
	W10019810	Right
	W10019800	Left
12	W10144431	Panel, Drawer
13		Front, Drawer
	9761747BL	Black
	9761747WH	White
	9761747BT	Biscuit
	W10140545	Stainless

Illus. No.	Part No.	DESCRIPTION
14		Handle, Drawer
	9761573BL	Black
	9761573WH	White
	9761573BT	Biscuit
	9761573SS	Stainless
15	3196537	Screw
16	W10153100	Cover, Terminal
17	9758676	Support, Element
18	9760775	Element, Warming Drawer
19	9763518	Enclosure, Warming Drawer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KESS907SBL02, KESS907SWW02, KESS907SBB02, KESS907SSS02
 (Black) (Designer White) (Pure Biscuit) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Control Panel
	W10117025	Black
	W10117027	White
	W10117026	Biscuit
	W10156271	Stainless
2	W10110246	Gasket, Console
3	W10181439	Control, Electric
4	W10105370	Shield, Console Vent
5	W10117524	Bracket, Console
6	3196160	Screw

Illus. No.	Part No.	DESCRIPTION
7	9761745	Bracket, Thermostat
8	W10116195	Gasket, Vent Shield
9	3196537	Screw
10	9780271	Screw
11	9761566	Membrane, Switch
12		Knob, Smart Dual LF,LR,RR
	W10130391	Black
	W10130392	White
	W10130393	Biscuit
	W10156260	Stainless


Illus. No.	Part No.	DESCRIPTION
13		Knob, Smart Single RF
	W10130387	Black
	W10130388	White
	W10130389	Biscuit
	W10156261	Stainless
14	3196068	Lens, Indicator Light
15	9763762	Dual Switch LF,LR,RR
16	9763761	Single Switch RF

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: KESS907SBL02, KESS907SWW02, KESS907SBB02, KESS907SSS02

(Black) (Designer White) (Pure Biscuit) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
2	4449154	Screw
3	9755543	Jack, Meat Probe
4	9755547	Lock Washer
5	9755546	Hex Nut


Illus. No.	Part No.	DESCRIPTION
6	4448717	Rack, Oven
7	9760768	Element, Bake
8	9755542	Probe, Meat
9	9760769	Element, Convection
10	9756690	Cover, Fan

Illus. No.	Part No.	DESCRIPTION
11	4455037	Tray, Hidden Bake
12	4450039	Cover, Bake Tray
13	W10116228	Motor, Convection
14	W10116349	Nut
15	W10116351	Blade, Fan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KESS907SBL02, KESS907SWW02, KESS907SBB02, KESS907SSS02
 (Black) (Designer White) (Pure Biscuit) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent Top
3	9759320	Blower
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
6	W10143041	Bracket, Terminal Box
7	4449809	Screw
8	4449040	Screw
9	4455352	Bracket, Blower

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KESS907SBL02, KESS907SWW02, KESS907SBB02, KESS907SSS02
 (Black) (Designer White) (Pure Biscuit) (Stainless)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

	72017	White
	261869	Citrine White
	72032	Black

PAINT, SPRAY

	350930	White
	261900	Citrine White
	830864	Black

ADHESIVE

	482338	Sealer, Silastic (3 oz.)
--	--------	-----------------------------

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

WIRING HARNESS PARTS

	W10137680	Harness, Main
	W10137677	Harness, Cooktop Electric
	W10157935	Harness, Switch
	9762921	Harness, Communication
	4452222	Spacer, Harness
	9763481	Harness, Ground Strap Edge Protector
	W10123242	19mm
	W10127413	38mm
	313660	Clip, Ground Wire
	W10177363	Grommet
	W10155291	Connector, Flex
	9757778	Bushing, Snap Split 1"
	W10076020	Gasket
	4449809	Screw
	112432	Nut
	4450800	Screw, Ground
	3400015	Screw, Ground

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Miscellaneous

	9782676	Anti-Tip Assembly Filler, Counter Top
	W10113902A	Black
	W10113903A	White
	W10113904A	Biscuit
	W10113901A	Stainless

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST