


COOKTOP PARTS

For Models: YKES907SB03, YKES907SP03, YKES907SS03
(Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10118260	Installation Instructions Use & Care Guide
	W10246111	English
	W10162197	French Tech Sheet
	W10220962	English
	W10220963	French
	9763467	Easy Set Guide
	9757680	Anti-Tip Instructions Safe Cooking Tips
	9762761	English
	W10065852	French
2	9758799	Bracket, Indicator Light
3	9761422	Frame, Cooktop Side
4		Cooktop
	W10110271	Black
	W10110269	White
5	8523739	Indicator, Lamp Hot Surface
6	9761724	Cover, Cooktop Rear
7	W10076030	Gasket
8	246119	Screw
9	9759944	Thermostat
10	9756821	Support, Wiring
11	9757825	Rail, Element Center
12		Element, Surface
	W10203294	LR,1800/1000W
	8523696	RF/1800W
	4453909	LF/RR,2500/1200W
13	9761423	Frame, Cooktop Front
14	3196537	Screw
15	341196	Thermostat
16	3196160	Screw
17	9763517	Rail, Element
18	9761768	Frame, Cooktop Rear
19	9759094	Spring, Locator

OVEN PARTS

For Models: YKES907SB03, YKES907SP03, YKES907SS03
 (Black) (White) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: YKES907SB03, YKES907SP03, YKES907SS03
(Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Trim, Side Right
	W10109540	Black
	W10109570	White
	W10140548	Stainless
		Left
	W10109490	Black
	W10109520	White
	W10140547	Stainless
2	3400832	Screw
3		Hinge Receiver
	4455606	Right
	4455605	Left
4	W10105790	Bumper, Door
5	3196537	Screw
6	3196160	Screw
7	8303099	Top Chassis
8	7101P426-60	Screw
9	4452158	Tube, Vent
10	W10067870	Lens, Light
11	W10009930	Oven Light, Assembly
12	4452166	Bulb, Light
13	4449154	Screw
14	W10115831	Frame, Front
15	W10074200	Gasket, Door
16	9757829	Bracket, Transformer
17	4452152	Bracket, Mounting

Illus. No.	Part No.	DESCRIPTION
18	9757685	Guide, Side Panel
19	4451478	Support, Insulation
20		Body, Side
	9760723PB	Black
	9760723PW	White
21	9757461	Bracket, Side Panel
22	W10195934	Latch, Motorized
23	9759242	Thermostat
24	9757811	Brace, Side Panel
25	4455641	Side, Chassis
26	9759761	Back, Chassis
27		Liner, Oven (Not Serviceable)
28	9759890	Clip, Side Panel
29	W10131825	Sensor
31	3196176	Screw
33	9759713	Base, Chassis
34	4448933	Retainer, Gasket
35	4448444	Grommet, Mounting Rail
36		Vent, Bottom Upper
	W10116899	Black
	W10116897	White
	W10160347	Stainless

Illus. No.	Part No.	DESCRIPTION
37		Vent, Bottom Lower
	W10153486	Black
	W10153488	White
	W10154789	Stainless
38	4449743	Screw
39	9759945	Standoff, Rear
40	9758583	Cover, Back
41	W10111628	Transformer, Control
42	7401P038-60	Block, Terminal
43	3400080	Screw
44	9759987	Box, Terminal
45	9759876	Cover, Terminal Box
46	9760481	Washer
47	9759722	Insulation, Body Side
48	W10181438	Appliance, Manager
49	W10083460	Slide, GOC
50	9756454	Bracket, Appliance Manager


**FOLLOWING PARTS
NOT ILLUSTRATED**

INSULATION

- 9756817 Insulation, Wrap
- 9756470 Insulation, Back

DOOR PARTS

For Models: YKES907SB03, YKES907SP03, YKES907SS03
(Black) (White) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


DOOR PARTS

For Models: YKESS907SB03, YKESS907SP03, YKESS907SS03
 (Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION
1	W10277749	Panel, Door
2	9757706	Glass, Inner
3	4451722	Insulation, Door
4	4457132	Retainer, Glass
5		Hinge, Oven Door
	9760579	Right
	9760574	Left
6	9759225	Glass, Inner
7	4457114	Shield, Heat Bottom
8	9759229	Bracket, Glass Side
9	4457104	Shield, Heat Top
10	9759225	Glass, Inner Door
11	9759230	Bracket, Central
12		Bracket, Handle
	W10246114	Right
	W10246113	Left
13		Badge
	W10243392	Black
	W10243393	White
	W10243391	Stainless
14		Assembly, Door Kit
	W10131888	Black
	W10131889	White
	W10155557	Stainless
15		Handle, Door
	W10448671	Black
	W10448672	White
	W10448670	Stainless
16	3196184	Screw
17	4448520	Bumper, Door

DRAWER PARTS

For Models: YKES907SB03, YKES907SP03, YKES907SS03
(Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Support, Drawer Rail
	9757687	Right
	9757686	Left
2	9763501BL	Support, Front & Rear
3		Brace, Drawer
	4453720	Right
	4453721	Left
4	7101P434-60	Screw
5		Side, Base
	9759953	Right
	9759954	Left


Illus. No.	Part No.	DESCRIPTION
6	W10058460	Foot
7	8274149	Thermistor
8	3196037	Foot Assembly
9	9763518	Enclosure, Warming Drawer
10	W10164163	Wrap, Warming Drawer
11		Drawer Slide
	W10155633	Right
	W10155632	Left
12	W10164169	Panel, Drawer

Illus. No.	Part No.	DESCRIPTION
13		Front, Drawer
	W10203760	Black
	W10203762	White
	W10203763	Stainless
14		Handle, Drawer
	W10292375	Black
	W10292379	White
	W10292374	Stainless
15	3196537	Screw
16	W10153100	Cover, Terminal
17	9758676	Support, Element
18	W10207401	Element, Warming Drawer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: YKESS907SB03, YKESS907SP03, YKESS907SS03
(Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10190660	Control Panel Black
	W10190661	White
	W10190662	Stainless
2	W10110246	Gasket, Console
3	W10181439	Control, Electric
4	W10105370	Shield, Console Vent
5	W10117524	Bracket, Console
6	3196160	Screw
7	9761745	Bracket, Thermostat


Illus. No.	Part No.	DESCRIPTION
8	W10116195	Gasket, Vent Shield
9	3196537	Screw
10	9780271	Screw
11	9761566	Membrane, Switch
12	3196068	Lens, Indicator
13	9763762	Duel, Switch LR,LF,RR
14	9763761	Single, Switch RF

Illus. No.	Part No.	DESCRIPTION
15		Knob, Smart Duel LR,LR,RR
	W10193255	Black
	W10193253	White
	W10156260	Stainless
16		Knob, Smart Single RF
	W10193259	Black
	W10193257	White
	W10156261	Stainless

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: YKES907SB03, YKES907SP03, YKES907SS03
(Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
2	4449154	Screw
3	9755546	Nut, Hex
4	9755547	Washer, Lock
5	9755543	Jack, Meat Probe


Illus. No.	Part No.	DESCRIPTION
6	W10179152	Rack, Oven
7	W10207398	Element, Bake
8	9755542	Probe, Meat
9	9760769	Element, Convection

Illus. No.	Part No.	DESCRIPTION
10	W10160868	Cover, Fan
11	4455037	Tray, Hidden Bake
12	4450039	Cover, Bake Tray
13	W10116228	Motor, Convection
14	W10116349	Nut
15	W10116351	Blade, Fan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: YKESS907SB03, YKESS907SP03, YKESS907SS03
 (Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent Top
3	9759320	Blower
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
6	7101P426-60	Screw
7	4449040	Screw
8	4455352	Bracket, Blower

OPTIONAL PARTS

For Models: YKES907SB03, YKES907SP03, YKES907SS03
(Black) (White) (Stainless)

Illus.	Part	
No.	No.	DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017	White
261869	Cord Brown
72032	Black

PAINT, SPRAY

350930	White
261900	Citrine White
830864	Black

ADHESIVE

591014	Adhesive Loctite (1/3 oz.)
482338	Sealer, Silastic (3 oz.)

WIRING HARNESS PARTS

W10118728	Harness, Main
W10215187	Harness, Cooktop Electric Switch
W10157935	Harness, Switch
9762921	Harness, Communication
9763481	Harness, Ground Strap
9761059	Power Cord
W10111397	Conduit, Slide-In
313660	Clip, Ground Wire
4448664	Clamp
9759877	Retainer, Strain Relief
9757778	Bushing, Snap, Split 1"
W10237644	Connector, Flex
W10076020	Gasket
4449809	Screw
7103P027-60	Nut
4450800	Screw, Ground
3400015	Screw, Ground

Miscellaneous

9782676	Anti-Tip Assembly Filler, Counter Top
W10113902A	Black
W10113903A	White
W10113901A	Stainless