

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


COOKTOP PARTS

For Models: KESS907XSP00
(Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10246119	Installation Instructions
	W10246111	Use & Care Guide
	W10220962	Tech Sheet
	9763467	Easy Set Guide
	9757680	Anti-Tip Instructions Safe Cooking Tips
	9762761	English
	W10065852	French
	W10075750	Instructions, Installer
2	246119	Screw
3	9761422	Frame, Cooktop Side
4	W10110271	Cooktop
5	9761724	Cover, Cooktop Rear
6	9763517	Rail, Element
7	W10076030	Gasket
8	9761768	Frame, Cooktop Rear
9	9759944	Thermostat
10	9756821	Support, Wiring
11	9757825	Rail, Element Center
12		Element, Surface
	W10203294	LR/1000W
	4453909	LF,RR/1200W
	8523696	RF/1800W
13	9761423	Frame, Cooktop Front
14	3196537	Screw
15	341196	Thermostat
16	9759094	Spring, Locator
17	8523739	Indicator Light, Hot Surface
18	9758799	Bracket, Indicator Light

OVEN PARTS

For Models: KESS907XSP00
(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KESS907XSP00
(Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Trim, Side
	W10140548	Right
	W10140547	Left
2	3400832	Screw
3		Hinge Receiver
	4455606	Right
	4455605	Left
4	W10105790	Bumper, Door
5	3196537	Screw
6	9759722	Insulation Body
		Side
7	8303099	Top Chassis
8	4449809	Screw
9	4452158	Tube, Vent
10	W10067870	Lens, Light
11	W10009930	Oven Light, Assembly
12	4452166	Bulb, Light
13	4449154	Screw
14	W10115831	Frame, Front
15	W10074200	Gasket, Door
16	9757829	Bracket, Transformer
17	4452152	Bracket, Mounting
18	9757685	Guide, Side Panel

Illus. No.	Part No.	DESCRIPTION
19	4451478	Support, Insulation
20	W10281880	Panel, Side
21	9757461	Bracket, Side Panel
22	W10195934	Latch, Motorized
23	9759242	Thermostat
24	9757811	Brace, Side Panel
25	4455641	Side, Chassis
26	9759761	Back, Chassis
27		Liner, Oven (Not Serviceable)
28	9759890	Clip, Side Panel
29	W10131825	Sensor
30	9759945	Standoff, Rear
31	3196176	Screw
32	9759885	Pad, Insulation
33	9759713	Base, Chassis
34	4448933	Retainer, Gasket
35	4448444	Grommet, Mounting Rail
36	W10160347	Vent, Bottom Upper
37	W10154789	Vent, Bottom Lower
38	4449743	Screw
39	9758583	Cover, Back

Illus. No.	Part No.	DESCRIPTION
40	9760481	Washer
41	W10111628	Transformer, Control
42	W10143304	Screw
43	3400080	Screw
44	W10165135	Box, Terminal
45	9757405	Cover, Terminal Box
46	9759721	Insulator, Terminal Box
47	W10245259	Block, Terminal
48	W10181438	Appliance, Manager
49	W10083460	Slide, GOC
50	9756454	Bracket, Appliance Manager
51	9759884	Insulation


**FOLLOWING PARTS
NOT ILLUSTRATED**

INSULATION

- 9756817 Insulation, Wrap
- 9756470 Insulation, Back

DOOR PARTS

For Models: KESS907XSP00
(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


DOOR PARTS

For Models: KESS907XSP00
(Stainless)

Illus. No.	Part No.	DESCRIPTION
1	9759413	Panel, Door
2	9757706	Glass, Inner
3	4451722	Insulation, Door
4	4457132	Retainer, Glass
5		Hinge, Oven Door
	9760579	Right
	9760580	Left
6	9759225	Glass, Inner
7	4457114	Shield, Heat Bottom
8	9759229	Bracket, Glass Side
9	4457104	Shield, Heat Top
10	9759225	Glass, Inner Door
11	9759230	Bracket, Central
12		Bracket, Handle
	W10246114	Right
	W10246113	Left
13	W10320959	Badge
14	W10246115	Door Assembly, Outer
15	W10246102	Handle, Door
16	7101P068-60	Screw
17	4448520	Bumper, Door

DRAWER PARTS

For Models: KESS907XSP00
(Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Support, Drawer Rail
	9757687	Right
	9757686	Left
2	9763501BL	Support, Front & Rear
3		Brace, Drawer
	4453720	Right
	4453721	Left
4	7101P434-60	Screw


Illus. No.	Part No.	DESCRIPTION
5		Side, Base
	9759953	Right
	9759954	Left
6	W10058460	Foot
7	8274149	Thermistor
8	3196037	Foot Assembly
9	9763518	Enclosure, Warming Drawer
10	W10164163	Drawer
11		Drawer Slide
	W10155633	Right
	W10155632	Left

Illus. No.	Part No.	DESCRIPTION
12	W10164169	Panel, Drawer
13	W10246103	Front, Drawer
14	W10246102	Handle, Drawer
15	3196537	Screw
16	W10153100	Cover, Terminal
17	9758676	Support, Element
18	W10207401	Element, Warming Drawer
19	3823F017-45	Spacer, Handle

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KESS907XSP00
(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10190662	Control Panel
2	W10110246	Gasket, Console
3	W10181439	Control, Electric
4	W10105370	Shield, Console Vent
5	W10117524	Bracket, Console
6	W10061760	Screw
7	9761745	Bracket, Thermostat


Illus. No.	Part No.	DESCRIPTION
8	W10116195	Gasket, Vent Shield
9	3196537	Screw
10	9763761	Single Switch RF
11	9761566	Membrane, Switch
12	W10246106	Knob, Dual LF,LR,RR

Illus. No.	Part No.	DESCRIPTION
13	W10246107	Knob, Single RF
14	3196068	Lens, Indicator Light
15	9763762	Dual Switch LF,LR,RR

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: KESS907SBL04, KESS907SWW04, KESS907SSS04
(Black) (Designer White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
2	4449154	Screw
3	W10179152	Oven Rack
4	W10207398	Bake Element
5	9755542	Meat Probe


Illus. No.	Part No.	DESCRIPTION
6	9760769	Element, Convection
7	W10160868	Baffle
8	4455037	Tray, Hidden Bake
9	4450039	Cover, Bake Tray
10	W10116228	Motor, Convection

Illus. No.	Part No.	DESCRIPTION
11	W10116349	Acorn Nut
12	W10116351	Blade, Fan
13	9755543	Jack, Meat Probe
14	9755547	Lock Washer
15	9755546	Hex Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KESS907XSP00
(Stainless)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent Top
3	9759320	Blower
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
6	W10143041	Bracket, Terminal Box
7	4449809	Screw (2)
8	4449040	Screw
9	4455352	Bracket, Blower

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KESS907XSP00
(Stainless)

Illus. No.	Part No.	DESCRIPTION
-------------------	-----------------	--------------------

Optional Parts Not Included

PAINT, TOUCH-UP (1/2oz.)

72017 White
261869 Cord Brown
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

ADHESIVE

482338 Sealer, Silastic
(3 oz.)

SPLICING WIRES--25FT.

LENGTH

WIRING HARNESS PARTS

W10137680 Harness, Main
W10198758 Harness, Cooktop
Electric
W10157935 Harness, Switch
9762921 Harness,
Communication
W10207713 Bushing, Snap
9763481 Harness, Ground
Strap
Edge Protector
W10123242 19mm
W10127413 38mm
313660 Clip, Ground Wire
W10177363 Grommet, Flex 60mm
W10237644 Connector, Flex
9757778 Bushing, Snap,
Split 1"
W10076020 Gasket
4449809 Screw
7103P027-60 Nut
4450800 Screw, Ground
3400015 Screw, Ground

Miscellaneous

9782676 Anti-Tip Assembly
W10113901A Filler, Counter
Top

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST