

COOKTOP PARTS


For Models: YKES908SS04

(Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10118260	Installation Instructions Use & Care Guide
	W10246111	English
	W10162197	French Tech Sheet
	W10112131	English
	W10112134	French
	9763467	Easy Set Guide
	9757680	Anti-Tip Instructions Safe Cooking Tips
	9762761	English
	W10065852	French
2	8285348	Module, Appliance Manager
3	9761422	Frame, Cooktop Side
4	W10110273	Cooktop
5	9757824	Rail, Element Side
6	9761638	Box, Tap Touch
7	W10076030	Gasket
8	4449745	Screw
9	9759944	Thermostat
10	9756821	Support, Wiring
11	9757825	Rail, Element Center
12		Element, Surface
	W10245533	LR/1000W
	8523045	RF/1500W
	W10248257	RR/1900W
	W10248260	LF/2300W
13	9761423	Frame, Cooktop Front
14	3196537	Screw
15	341196	Thermostat
16	3196160	Screw
17	9761663	Seal, Heat
18	9757815	Support, Module
19	9759094	Spring, Locator
20	9761768	Frame, Cooktop Rear
21	9763517	Rail, Element
22	246119	Screw
23	9761723	Cover, Cooktop Rear
24	9757063	Module, Tap Touch

OVEN PARTS

For Models: YKESS908SS04
(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: YKES908SS04
(Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Trim, Side
	W10140548	Right
	W10140547	Left
2	3400832	Screw
3		Hinge Receiver
	4455606	Right
	4455605	Left
4	W10105790	Bumper, Door
5	3196537	Screw
6	3196160	Screw
7	8303099	Top Chassis
8	4449809	Screw
9	4452158	Tube, Vent
10	W10067870	Lens, Light
11	W10009930	Oven Light, Assembly
12	4452166	Bulb, Light
13	4449154	Screw
14	W10115831	Frame, Front
15	W10074200	Gasket, Door
16	9757829	Bracket, Transformer

Illus. No.	Part No.	DESCRIPTION
17	4452152	Bracket, Mounting
18	9757685	Guide, Side Panel
19	4451478	Support, Insulation
20	9760723PB	Body, Side
21	9757461	Bracket, Side Panel
22	W10195934	Latch, Motorized
23	9759242	Thermostat
24	9757811	Brace, Side Panel
25	4455641	Side, Chassis
26	9759761	Back, Chassis
27		Liner, Oven (Not Serviceable)
28	9759890	Clip, Side Panel
29	W10131825	Sensor
31	3196176	Screw
33	9759713	Base, Chassis
34	4448933	Retainer, Gasket
35	4448444	Grommet, Mounting Rail
36	W10160347	Vent, Bottom Upper
37	W10154789	Vent, Bottom Lower
38	4449743	Screw
41	W10111628	Transformer, Control

Illus. No.	Part No.	DESCRIPTION
42	7401P038-60	Block, Terminal
43	3400080	Screw
44	9759987	Box, Terminal
45	9759876	Cover, Terminal Box
48	W10181438	Appliance, Manager
49	W10083460	Slide, GOC
50	9756454	Bracket, Appliance Manager
52	9759722	Insulation, Body Side
53	9760481	Washer
54	9758583	Cover, Back
56	9759945	Standoff, Rear


**FOLLOWING PARTS
NOT ILLUSTRATED**

INSULATION

- 9756817 Insulation, Wrap
- 9756470 Insulation, Back

DOOR PARTS

For Models: YKES908SS04
(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


DOOR PARTS

For Models: YKES908SS04
(Stainless)

Illus. No.	Part No.	DESCRIPTION
1	W10277749	Panel, Door
2	9757706	Glass, Inner
3	4451722	Insulation, Door
4	4457132	Retainer, Glass
5		Hinge, Oven Door
	9760579	Right
	9760574	Left
6	9759225	Glass, Inner
7	4457114	Shield, Heat Bottom
8	9759229	Bracket, Glass Side
9	4457104	Shield, Heat Top
10	9759225	Glass, Inner Door
11	9759230	Bracket, Central
12		Bracket, Handle
	W10246114	Right
	W10246113	Left
13	W10243391	Badge
14	W10155557	Assembly, Door Kit
15	W10292380	Handle, Door
16	3196184	Screw
19	4448520	Bumper, Door

DRAWER PARTS

For Models: YKESS908SS04
(Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Support, Drawer Rail
	9757687	Right
	9757686	Left
2	9763501BL	Support, Front & Rear
3		Brace, Drawer
	4453720	Right
	4453721	Left

Illus. No.	Part No.	DESCRIPTION
5		Side, Base
	9759953	Right
	9759954	Left
6	W10058460	Foot
7	8274149	Thermistor
8	3196037	Foot Assembly
10	W10164163	Drawer
11		Drawer Slide
	W10155633	Right
	W10155632	Left


Illus. No.	Part No.	DESCRIPTION
12	W10164169	Panel, Drawer
13	W10203763	Front, Drawer
14	W10292374	Handle, Drawer
15	3196537	Screw
16	W10153100	Cover, Terminal
17	9758676	Support, Element
18	W10207401	Element, Warming Drawer
19	9763518	Enclosure, Warming Drawer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: YKES908SS04

(Stainless)




Illus. No.	Part No.	DESCRIPTION
1	W10156272	Control Panel
2	W10110246	Gasket, Console
3	W10181439	Control, Electric
4	W10105370	Shield, Console Vent
5	W10117524	Bracket, Console
6	3196160	Screw
7	9761745	Bracket, Thermostat
8	W10116195	Gasket, Vent Shield
9	3196537	Screw
10	9780271	Screw
11	9761566	Membrane, Switch

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: YKESS908SS04

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
2	4449154	Screw
6	W10179152	Rack, Oven
7	W10207398	Element, Bake
8	9755542	Probe, Meat

Illus. No.	Part No.	DESCRIPTION
9	9760769	Element, Convection
10	W10160868	Cover, Fan
11	4455037	Tray, Hidden Bake
12	4450039	Cover, Bake Tray
13	W10116228	Motor, Convection


Illus. No.	Part No.	DESCRIPTION
14	W10116349	Nut
15	W10116351	Blade, Fan
16	9755543	Jack, Meat Probe
17	9755547	Lock Washer
18	9755546	Hex Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: YKESS908SS04

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent Top
3	9759320	Blower
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
7	4449809	Screw
10	4449040	Screw
11	4455352	Bracket, Blower

OPTIONAL PARTS (NOT INCLUDED)

For Models: YKESS908SS04

(Stainless)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

PAINT, TOUCH-UP (1/2oz.)

	72017	White
	261869	Cord Brown
	72032	Black

PAINT, SPRAY

	350930	White
	261900	Citrine White
	830864	Black

ADHESIVE

	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

WIRING HARNESS PARTS

	W10118728	Harness, Main
	9761059	Power Cord
	W10155097	Cable, Board Connection
	W10157935	Harness, Switch
	9762921	Harness, Communication
	9759877	Retainer, Strain Relief
	9763481	Harness, Ground Strap
	W10115168	Cooktop, Tap Touch Switch
	W10111397	Conduit Slide-In
	313660	Clip, Ground Wire
	4448664	Clamp
	9756675	Grommet, Flexible
	9757778	Bushing, Snap, Split 1"
	W10076020	Gasket
	4449809	Screw
	7103P027-60	Nut
	W10237644	Connector, Flex
	4450800	Screw, Ground
	3400015	Screw, Ground

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

Miscellaneous

	9782676	Anti-Tip Assembly
	W10113901A	Filler, Counter Top

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST