

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# COOKTOP PARTS

For Models: KESS908SPS05


(Stainless)

<b>Illus.</b>	<b>Part</b>	<b>DESCRIPTION</b>
<b>No.</b>	<b>No.</b>	
1		Literature Parts
	W10075750	Instructions, Installer
	W10246119	Installation Instructions
	W10246111	Use & Care Guide
	W10112131	Tech Sheet
	9763467	Easy Set Guide
	9757680	Anti-Tip Instructions
	9762761	Safe Cooking Tips English
	W10065852	French
2	W10181438	Module, Appliance Manager
3	9761422	Frame, Cooktop Side
4		Cooktop
	W10110273	Black/Stainless
5	9757824	Rail, Element Side
6	9761638	Box, Tap Touch
7	W10076030	Gasket
8	4449745	Screw
9	9759944	Thermostat
10	9756821	Support, Wiring
11	9757825	Rail, Element Center
12		Element, Surface
	W10248257	(LR)1800/1000W
	8523045	(RF)1500W
	W10245533	(RR)2000/1000W
	W10248260	(LF)2300/1600/800W
13	9761423	Frame, Cooktop Front
14	3196537	Screw
15	341196	Thermostat
16	9757063	Module, Tap Touch
17	9761663	Seal, Heat
18	9757815	Support, Module
19	9759094	Spring, Locator
20	9761768	Frame, Cooktop Rear
21	9763517	Rail, Element
22	246119	Screw
23	9761723	Cover, Cooktop Rear

# OVEN PARTS

For Models: KESS908SPS05

(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS

For Models: KESS908SPS05  
(Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Trim, Side Right
	W10140548	Stainless Left
	W10140547	Stainless
2	3400832	Screw
3		Hinge Receiver
	4455606	Right
	4455605	Left
4	W10105790	Bumper, Door
5	3196537	Screw
6	9758583	Cover, Back
7	8303099	Top Chassis
8	3177991	Screw
9	4452158	Tube, Vent
10	W10067870	Lens, Light
11	W10009930	Oven Light, Assembly
12	4452166	Bulb, Light
13	4449154	Screw
14	W10115831	Frame, Front
15	W10074200	Gasket, Door
16	9757829	Bracket, Transformer
17	4452152	Bracket, Mounting

Illus. No.	Part No.	DESCRIPTION
18	9757685	Guide, Side Panel
19	4451478	Support, Insulation
20		Body, Side
	W10281880	Black/Stainless
21	9757461	Bracket, Side Panel
22	W10195934	Latch, Motorized
23	9759242	Thermostat
24	9757811	Brace, Side Panel
25	4455641	Side, Chassis
26	9759761	Back, Chassis
27		Liner, Oven (Not Serviceable)
28	9759890	Clip, Side Panel
29	W10131825	Sensor
30	W10083460	Slide, GOC
31	3196176	Screw
32	3400080	Screw
33	9759713	Base, Chassis
34	4448933	Retainer, Gasket
35	4448444	Grommet, Mounting Rail
36		Vent, Bottom Upper
	W10140533	Stainless
37		Vent, Bottom Lower
	W10160347	Stainless
38	4449743	Screw
39	W10165135	Box, Terminal

Illus. No.	Part No.	DESCRIPTION
40	W10245259	Block, Terminal
41	W10111628	Transformer, Control
42	9759945	Standoff, Rear
43	9757405	Cover, Terminal Box
44	9759721	Insulator, Terminal Box
45	8285348	Appliance, Manager
46	9756454	Bracket, Appliance Manager
47	9759884	Insulation
48	9759722	Insulation, Body Side
49	9760481	Washer
50	9759885	Pad, Insulation

**FOLLOWING PARTS  
NOT ILLUSTRATED**


**INSULATION**

- 9756817 Insulation, Wrap
- 9756470 Insulation, Back

# DOOR PARTS

For Models: KESS908SPS05

(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS


For Models: KESS908SPS05  
(Stainless)

Illus. No.	Part No.	DESCRIPTION
1	W10277749	Liner, Door
2	9757706	Glass, Inner
3	4451722	Insulation, Door
4	4457132	Retainer, Glass
5		Hinge, Oven Door
	9760579	Right
	9760574	Left
6	9759225	Glass, Inner
7	4457114	Shield, Heat Bottom
8	9759229	Bracket, Glass Side
9	4457104	Shield, Heat Top
10	9759225	Glass, Inner Door
11	9759230	Bracket, Central
12		Bracket, Handle
	W10246114	Right
	W10246113	Left
13		Badge
	W10243391	Stainless
14		Assembly, Door Kit
	W10155557	Stainless
15		Handle, Door
	W10292380	Stainless
16	3196184	Screw
17	4448520	Bumper, Door

# DRAWER PARTS

For Models: KESS908SPS05

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Support, Drawer Rail
	9757687	Right
	9757686	Left
2	9763501BL	Support, Front & Rear
3		Brace, Drawer
	4453720	Right
	4453721	Left

Illus. No.	Part No.	DESCRIPTION
4	9758676	Support, Element Side, Base
5		Right
	9759953	Right
	9759954	Left
6	W10058460	Foot
7	8274149	Thermistor
8	3196037	Foot Assembly
9	9763518	Enclosure, Warming Drawer
10	W10164163	Drawer
11		Drawer Slide
	W10155633	Right
	W10155632	Left


Illus. No.	Part No.	DESCRIPTION
12	W10164169	Panel, Drawer
13		Front, Drawer
	W10203763	Stainless
14		Handle, Drawer
	W10292374	Stainless
15	3196537	Screw
16	W10153100	Cover, Terminal
17	W10207401	Element, Warming Drawer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: KESS908SPS05

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10156272	Control Panel Stainless
2	W10110246	Gasket, Console
3	W10181439	Control, Electric
4	W10105370	Shield, Console Vent
5	W10117524	Bracket, Console
6	3179559	Screw
7	9761745	Bracket, Thermostat
8	W10116195	Gasket, Vent Shield
9	3196537	Screw
10	9761566	Membrane, Switch


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# INTERNAL OVEN PARTS

For Models: KESS908SPS05

(Stainless)




Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
2	4449154	Screw
6	W10179152	Rack, Oven
7	W10207398	Element, Bake
8	9755542	Probe, Meat
9	9760769	Element, Convection
10	W10160868	Cover, Fan
11	4455037	Tray, Hidden Bake
12	4450039	Cover, Bake Tray
13	W10116228	Motor, Convection
14	W10116349	Nut
15	W10116351	Blade, Fan
16	9755543	Jack, Meat Probe
17	9755547	Lock Washer
18	9755546	Hex Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP VENTING PARTS

For Models: KESS908SPS05

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent Top
3	9759320	Blower
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
6	W10143041	Bracket, Terminal Box
7	7101P426-60	Screw
8	4449040	Screw
9	4455352	Bracket, Blower

# OPTIONAL PARTS

For Models: KESS908SPS05

(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<b>OPTIONAL PARTS NOT INCLUDED</b>			<b>WIRING HARNESS PARTS</b>			<b>Miscellaneous</b>		
<b><u>PAINT, TOUCH-UP (1/2oz.)</u></b>								
	72017	White		W10137680	Harness, Main		9782676	Anti-Tip Assembly
	261869	Cord Brown		W10155097	Cable, Board Connection			Filler, Counter Top
	72032	Black		W10157935	Harness, Switch		W10113902A	Black
				9762921	Harness, Communication		W10113903A	White
				9763481	Harness, Ground Strap		W10113901A	Stainless
				W10137678	Harness, Cooktop Tap Touch			
				313660	Clip, Ground Wire Grommet, Flexible			
				9756675	77mm			
				W10177363	60mm			
				9757778	Bushing, Snap, Split 1"			
				W10076020	Gasket			
				4449809	Screw			
				7103P027-60	Nut			
				4454842	Tie, Cable			
				4450800	Screw, Ground			
				3400015	Screw, Ground			
<b><u>PAINT, SPRAY</u></b>								
	350930	White						
	261900	Citrine White						
	830864	Black						
<b><u>ADHESIVE</u></b>								
	482338	Sealer, Silastic (3 oz.)						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST