


COOKTOP PARTS

For Models: KESS908SPS06
(Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10075750	Instructions, Installer
	W10440541	Installation Instructions
	W10449874	Use & Care Guide
	W10112131	Tech Sheet
	9763467	Easy Set Guide
	W10306542	Anti-Tip Instructions
		Safe Cooking Tips
	9762761	English
	W10065852	French
2	W10181438	Module, Appliance Manager
3	9761422	Frame, Cooktop Side
4		Cooktop
	W10110273	Black/Stainless
5	9757824	Rail, Element Side
6	9761638	Box, Tap Touch
7	W10076030	Gasket
8	4449745	Screw
9	9759944	Thermostat
10	9756821	Support, Wiring
11	9757825	Rail, Element Center
12		Element, Surface
	W10248257	(LR)1800/1000W
	8523045	(RF)1500W
	W10245533	(RR)2000/1000W
	W10248260	(LF)2300/1600/800W
13	9761423	Frame, Cooktop Front
14	3196537	Screw
15	341196	Thermostat
16	9757063	Module, Tap Touch
17	9761663	Seal, Heat
18	9757815	Support, Module
19	9759094	Spring, Locator
20	9761768	Frame, Cooktop Rear
21	9763517	Rail, Element
22	246119	Screw
23	9761723	Cover, Cooktop Rear

OVEN PARTS

For Models: KESS908SPS06
(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


OVEN PARTS

For Models: KESS908SPS06
(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side Right	19	4451478	Support, Insulation Body, Side	41	W10111628	Transformer, Control
	W10140548	Stainless Left	20	W10281880	Black/Stainless	42	9759945	Standoff, Rear
	W10140547	Stainless	21	9757461	Bracket, Side Panel	43	9757405	Cover, Terminal Box
2	3400832	Screw	22	W10195934	Latch, Motorized	44	9759721	Insulator, Terminal Box
3		Hinge Receiver	23	9759242	Thermostat	45	8285348	Appliance, Manager
	4455606	Right	24	9757811	Brace, Side Panel	46	9756454	Bracket, Appliance Manager
	4455605	Left	25	4455641	Side, Chassis	47	9759884	Insulation
4	W10105790	Bumper, Door	26	9759761	Back, Chassis	48	9759722	Insulation, Body Side
5	3196537	Screw	27		Liner, Oven (Not Serviceable)	49	9760481	Washer
6	9758583	Cover, Back	28	9759890	Clip, Side Panel	50	9759885	Pad, Insulation
7	8303099	Top Chassis	29	W10131825	Sensor	FOLLOWING PARTS NOT ILLUSTRATED		
8	3177991	Screw	30	W10083460	Slide, GOC	INSULATION		
9	4452158	Tube, Vent	31	3196176	Screw		9756817	Insulation, Wrap
10	W10067870	Lens, Light	32	3400080	Screw		9756470	Insulation, Back
11	W10009930	Oven Light, Assembly	33	9759713	Base, Chassis			
12	4452166	Bulb, Light	34	4448933	Retainer, Gasket			
13	4449154	Screw	35	4448444	Grommet, Mounting Rail			
14	W10115831	Frame, Front	36		Vent, Bottom Upper			
15	W10074200	Gasket, Door		W10140533	Stainless			
16	9757829	Bracket, Transformer	37		Vent, Bottom Lower			
17	4452152	Bracket, Mounting		W10160347	Stainless			
18	9757685	Guide, Side Panel	38	4449743	Screw			
			39	W10165135	Box, Terminal			
			40	W10245259	Block, Terminal			

DOOR PARTS

For Models: KESS908SPS06
(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


DOOR PARTS

For Models: KESS908SPS06
(Stainless)

Illus. No.	Part No.	DESCRIPTION
1	W10277749	Liner, Door
2	9757706	Glass, Inner
3	4451722	Insulation, Door
4	4457132	Retainer, Glass
5		Hinge, Oven Door
	9760579	Right
	9760574	Left
6	9759225	Glass, Inner
7	4457114	Shield, Heat Bottom
8	9759229	Bracket, Glass Side
9	4457104	Shield, Heat Top
10	9759225	Glass, Inner Door
11	9759230	Bracket, Central
12		Bracket, Handle
	W10246114	Right
	W10246113	Left
13		Badge
	W10243391	Stainless
14		Assembly, Door Kit
	W10155557	Stainless
15		Handle, Door
	W10448670	Stainless
16	3196184	Screw
17	4448520	Bumper, Door

DRAWER PARTS

For Models: KESS908SPS06
(Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Support, Drawer Rail
	9757687	Right
	9757686	Left
2	9763501BL	Support, Front & Rear
3		Brace, Drawer
	4453720	Right
	4453721	Left
4	9758676	Support, Element


Illus. No.	Part No.	DESCRIPTION
5		Side, Base
	9759953	Right
	9759954	Left
6	W10058460	Foot
7	8274149	Thermistor
8	3196037	Foot Assembly
9	9763518	Enclosure, Warming Drawer
10	W10164163	Drawer

Illus. No.	Part No.	DESCRIPTION
11		Drawer Slide
	W10155633	Right
	W10155632	Left
12	W10164169	Panel, Drawer
13		Front, Drawer
	W10203763	Stainless
14		Handle, Drawer
	W10292374	Stainless
15	3196537	Screw
16	W10153100	Cover, Terminal
17	W10207401	Element, Warming Drawer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KESS908SPS06
(Stainless)




Illus. No.	Part No.	DESCRIPTION
1		Control Panel Stainless
2	W10156272	Gasket, Console
3	W10181439	Control, Electric
4	W10105370	Shield, Console Vent
5	W10117524	Bracket, Console
6	3179559	Screw
7	9761745	Bracket, Thermostat
8	W10116195	Gasket, Vent Shield
9	3196537	Screw
10	9761566	Membrane, Switch

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: KESS908SPS06
(Stainless)




Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
2	4449154	Screw
6	W10179152	Rack, Oven
7	W10207398	Element, Bake
8	9755542	Probe, Meat
9	9760769	Element, Convection
10	W10160868	Cover, Fan
11	4455037	Tray, Hidden Bake
12	4450039	Cover, Bake Tray
13	W10116228	Motor, Convection
14	W10116349	Nut
15	W10116351	Blade, Fan
16	9755543	Jack, Meat Probe
17	9755547	Lock Washer
18	9755546	Hex Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KESS908SPS06
(Stainless)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent Top
3	9759320	Blower
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
6	W10143041	Bracket, Terminal Box
7	7101P426-60	Screw
8	4449040	Screw
9	4455352	Bracket, Blower

OPTIONAL PARTS

For Models: KESS908SPS06
(Stainless)

Illus.	Part	
No.	No.	DESCRIPTION

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH-UP (1/2oz.)

72017 White
261869 Cord Brown
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

ADHESIVE

482338 Sealer, Silastic
(3 oz.)

WIRING HARNESS PARTS

W10137680 Harness, Main
W10155097 Cable, Board
Connection
W10157935 Harness, Switch
9762921 Harness,
Communication
9763481 Harness, Ground
Strap
W10137678 Harness, Cooktop
Tap Touch
313660 Clip, Ground Wire
Grommet, Flexible
9756675 77mm
W10177363 60mm
9757778 Bushing, Snap,
Split 1"
W10076020 Gasket
4449809 Screw
7103P027-60 Nut
4454842 Tie, Cable
4450800 Screw, Ground
3400015 Screw, Ground

Miscellaneous

9782676 Anti-Tip Assembly
Filler, Counter
Top
W10113902A Black
W10113903A White
W10113901A Stainless