




27" ELECTRIC DRYER

MODELS:

WED8600YW2 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6	W10432259	Control, Electronic	15	8558863	Bracket, Console
	W10398830	Guide, Use & Care	7	8572039	Seal, User Interface	16	337686	Screw
	W10392124	Instructions, Installation	8	W10211337	Bracket, Machine Controller			
	W10403269	Tech Sheet	9	W10003770	Screw			
2		Console	10	W10112673	Clip, Console			
	W10403678	White	11		Top			
3	W10388674	Assembly, User Interface		W10211339	White			
4	8564265	Cover, Rear (User Interface)	12	W10131402	Screw			
5	W10211335	Knob Assembly	13	W10185554	Foam, Top			
			14	W10392403	Harness, Electric			


CABINET PARTS



CABINET PARTS

<u>Illus.</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1	98234	Clip, Ground		18	8547171	Pulley, Motor		39	W10221653	Seal, Door
	2	3390631	Screw		19	3394083	Clip, Front Panel		40	3393008	Screw
	3	693995	Screw		20	W10111888	Plug, Strike		41	W10350907	Door Switch Assembly
	4	3397659	Block, Terminal		21		Hinge, Spring Assembly		42		Panel, Front
	5	W10411937	Switch, Broken Belt			8565018	White			W10463261	White
	6	342055	Screw		22	W10316529	Seal, Foam		43	8576625	Lock, Top Front
	7		Cabinet		23	W10076050	Seal, Window		44	W10044490	Seal, Front Panel
		W10183827	White		24	3350013	Foam		45	W10110241	Cover, Terminal Block
	8	W10363894	Foot, Dryer		25	W10402478	Handle, Door Cover		46	238088	Hinge, Top
		279810	Foot, Optional (Extended Length Package Of 2) (Not Included)		26	3393657	Restrainer, Belt		47	8558846	Glass, Inner Door
	9	660658	Clamp, Motor		27	W10396036	Motor Assembly (60 Hertz)		48	308499	Palnut
	10	W10446781	Spring, Idler		28	W10140148	Panel, Rear		49	3389682	Space, Toe Panel
	11	3389420	Screw		29	8544743	Pulley, Blower				Optional Parts Not Included Dryer Exhaust Kit (For Side & Bottom Venting)
	12	W10363887	Riser, Full		30	8547157	Belt, Drive				
	13	W10547292	Idler Assembly		31	W10111905	Assembly, Door Catch				
	14	279318	Terminal, Brass & Tinned (Includes Terminal Block Screw Kit)		32	8547158	Bracket, Motor				
	15	8578931	Window, Outer Door		33	279393	Screw Kit, Terminal Block				
	16		Door, Outer		34	8571357	Door, Inner				
		8571365	White		35	8568303	Locator, Snap-Down				
	17	8533974	Screw		36	W10111906	Strike & Plate Assembly				
					37	3400805	Screw				
					38	W10144494	Plug, Hole				

BULKHEAD PARTS



BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359271	Shaft, Drum Roller - Right Hand Thread	26	W10219342	Screw	53	8563860	Baffle, Drum
2	90767	Screw	27	W10521119	Seal, Drum	54	8557244	Bulkhead, Front
3	3390631	Screw	28	8573070	Clip, Lint Duct	55	8544718	Duct, Inlet Blower
4	3394984	Door, Lint Screen	29	8544742	Belt, Blower	56	W10130506	Valve & Hose Assembly
5	8544730	Air Duct Assembly	30	693995	Screw	57	W10129424	Valve & Bracket Assembly
6	697813	Seal, Outlet Housing	31	8544770	Housing Tab, Heater Box	58	W10410316	Nozzle & Hose Assembly (Includes Nozzle & Screen Assembly)
7	8544739	Pulley, Blower	32	W10533417	Pipe, Exhaust	59	W10347743	Hose (Not Serviced)
8	3934666	Nut, Hex	33	3406124	Bulb, Light	60	W10277503	Nozzle & Screen Assembly
9	8544721	Seal, Lint Duct	34	3387223	Sensor, Electrode	61	W10044628	Nut, Brass
10	3402841	Lens, Drum Light	35	3977373	Bracket, Drum Light	62	W10044579	Washer, Nozzle
11	8573068	Seal, Blower Cover	36	W10214261	Socket, Light	63	W10044599	Clip, Push To Connect
12	3387230	Screw	37	8544737	Wheel, Blower	64	W10044605	Coupling, Hose
13	697814	Seal, Drum Front	38	8544776	Flange, Heater Box	65	W10160575	Cover, Myst Valve
14	8544772	Heater Element	40	W10049370	Screen, Lint	66	W10435653	Sleeve, Tube
15	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	41	8544741	Bracket, Blower Housing	67	W10475158	Shield, Dryer Exhaust
16	W10001120	Nut, Hex (Left Hand Thread)	42	8577274	Thermistor			
17	W10139797	Bulkhead, Rear	43	3390647	Screw			
18	3387459	Washer	44	W10256512	Housing, Blower			
19	W10359272	Shaft, Drum Roller - Left Hand Thread	45	8544786	Lint Duct Assembly			
20	690997	Washer, Tri Ring	46	8544769	Housing Slot, Heater Box			
21	W10314171	Roller, Support	47	8318314	Cut-Off, Thermal			
22	3350424	Screw	48	8557403	Thermostat, High Limit			
23	3394985	Housing, Outlet	49	8544729	Bracket, Heater Box			
24	3394986	Spring, Lint Screen Door	50	8544719	Cover, Blower			
25	W10549614	Drum Assembly	51	3390719	Thermal Fuse (91C)			
			52	8544723	Grill, Outlet			

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	80047	Kit, Dryer Repair
	8522199	Kit, Dryer Vent Testing
	49611	Kit, Side Venting
	W10323246	Kit, 4-Way Venting
	W10518409	Tube Extension

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White

MISCELLANEOUS PARTS BAG

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10434773	Bag Assembly
	W10439654	5' Hose Inlet
	W10439655	2' Hose Inlet
	W10242307	Washer, Inlet Hose
	3357450	Washer, Hose Adapter
	W10336486	Connector, Hose -"Y"

REQUIREMENTS TO SEE IF ONE OF THESE MEETS YOUR NEEDS.

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	PT220L	4', 30 Amp, 4 Wire, Dryer Cord
	PT400L	4', 30 Amp, 4 Wire, Dryer Cord
	PT600L	6', 30 Amp, 4 Wire, Dryer Cord

ACCESSORY PARTS|THE FOLLOWING POWER CORD CAN BE ORDERED. IMPORTANT: CHECK LOCAL WIRING CODE